

Ansoft

Ansoft Designer

Circuit, System, and Planar Electromagnetics

Ansoft Designer - x400_tdr_sim_orig - X400_TDR_Simulation2 - Schematic

File Edit View Project Circuit Tools Window Help

XY Plot 1 XY Plot 2

2.1

The screenshot displays the Ansoft Designer interface with several windows:

- Schematic View:** Shows a circuit diagram for "x400_tdr_sim_orig" with components like resistors (R1, R2), capacitors (C1, C2), and voltage sources (V1, V2). A parameter table for V1 is shown below.
- XY Plot 1:** A time-domain plot showing voltage versus time (ns) for two signals. One signal shows a transient response with multiple peaks and troughs, while the other is a steady-state waveform.
- XY Plot 2:** A time-domain plot showing voltage versus time (ns) for another signal, showing a sharp rise followed by a decay.
- Layout View:** Shows a 3D perspective of a printed circuit board (PCB) layout with green traces and pads.
- Project Explorer:** Lists the project structure including Circuits, Data, Excitations, Ports, Analysis (Transient, Optetrics), Results, and Definitions.
- Component Catalog:** Shows various electronic components available for selection.
- Search Bar:** Allows users to search for specific components or terms.



Designer 2.1 Training Workbook

Circuit, System, and Planar EM



▲ Introduction

- ▲ Starting Ansoft Designer
- ▲ Ansoft Designer Desktop
- ▲ Converting Older Serenade or Ensemble files to Ansoft Designer
- ▲ Opening an Ansoft Designer project

▲ Examples

- ▲ Chapter 1.0 - Circuit Examples
- ▲ Chapter 2.0 - Planar EM Examples
 - ▲ Chapter 2.1 - Antenna Examples
 - ▲ 2.1.1 - Probe Feed Patch Antenna
 - ▲ 2.1.2 - Finite Ground Probe Feed Patch Antenna
 - ▲ 2.1.3 - Slot Coupled Patch Antenna
 - ▲ 2.1.4 - 2.4GHz ISM Circular Polarized Patch Antenna
 - ▲ 2.1.5 - Frequency Selective Surface (FSS) Jerusalem Cross
 - ▲ Chapter 2.2 - Microwave Examples
 - ▲ 2.2.1 - Ring Hybrid
 - ▲ Chapter 2.3 - Filter Examples
 - ▲ 2.3.1 - Low Pass Elliptic Filter
 - ▲ 2.3.2 - Bandstop Microstrip Filter
 - ▲ 2.3.3 - CPW Bandpass Filter
- ▲ Chapter 3.0 - System Examples
- ▲ Chapter 4.0 - Nexxim Examples
 - ▲ Chapter 4.1 - Mixer Example
 - ▲ 4.1.1 - DC Analysis
 - ▲ 4.1.2 - AC Analysis
- ▲ Chapter 5.0 - Signal Integrity Examples (Circuit/System/Planar EM)
 - ▲ Chapter 5.1 - Differential Pair
 - ▲ 5.1.1 - Circuit - S-Parameters
 - ▲ 5.1.2 - Circuit - Transient
 - ▲ 5.1.3 - System - Eye Diagram
 - ▲ 5.1.4 - Planar EM
 - ▲ Chapter 5.2 - Segmented Ground
 - ▲ 5.2.1 - Planar EM
 - ▲ 5.2.2 - Circuit - TDR